


20.8 cm (8-3/16")

# HAND DRYER FIXING TEMPLATE POSITION CARD

FIX THIS CARD TO THE WALL.  
DRILL 4 HOLES (A,B,C,D 8mm DIAMETER 35mm DEEP)

**EcoSTORM**  
HAND DRYER



12.8 cm (5-3/64")

## FIXING DETAIL (READ IN CONJUNCTION WITH LEAFLET ENCLOSED)

- 1) PLACE TEMPLATE ON WALL AND DRILL 4 HOLES 8mm DIAMETER.
- 2) SECURE THE BASE PLATE ON THE WALL WITH THE 4 WALL PLUGS & SCREWS PROVIDED.
- 3) CONNECTIONS:
  - A. CONNECT THE LIVE WIRE RED (OR BROWN) TO THE TERMINAL BLOCK MARKED "L".
  - B. CONNECT THE NEUTRAL WIRE BLACK (OR BLUE) TO THE TERMINAL BLOCK MARKED "N".
  - C. CONNECT THE EARTH WIRE GREEN AND YELLOW (OR GREEN), NOTE BARE EARTH WIRES SHOULD BE SLEEVED WITH GREEN AND YELLOW OR GREEN SLEEVING TO THE EARTH WASHER MARKED WITH THE EARTH SYMBOL "⊕".

THIS UNIT MUST BE FITTED AND SERVICED BY SUITABLY QUALIFIED PERSONNEL