### DRYER MOUNTING TEMPLATE

## Fix this card on the wall.

**Drill 4 holes** 

(A. B. C. D. 5/16" (8 mm) diameter: 1-3/8" (35 mm) depth.)

#### **CONNECT DESCRIPTION**

- 1. Secure the base plate on the wall provided.
- 2. The conduit in place by suitable 1/2 inch trade conduit fitting.
- 3. Connections:

8-27/64" (214 mm)

- A. Connect the live wire colored red (or brown) to The terminal block where marked "L".
- B. Connect the neutral wire colored black (or blue) To the terminal block where marked "N".
- C. Connect the earth wire colored green and yellow (or green, note bare earth wires should be sleeved With green and yellow or green sleeving) to the Ground washer where marked with the earth symbol. 

  ③

| <b>Required Heights</b> |     |
|-------------------------|-----|
| Men's                   | 43" |
| Ladies                  | 41" |
| Children, ages 11-17    | 39" |
| Children, ages 3-10     | 33" |
| Handicanned             | 35" |

# BLUSTORM



**HAND DRYER** 


17/64" (6.5 mm)

Ø22 (Ø7/8")

ELEC. K.O

#### **Important Information**

This Product falls within the scope of the Waste Electrical & Electronic Equipment Directive 2002/96 EC. (WEEE)





This Product should not be disposed of with household waste
Please recycle where facilities exist.
Check with your local authority for

39" (100 cm) from the ground is suitable